Preliminaries

Installations

In order to work through this notebook, you must install pyulog and pandas.

• Install pyulog:

```
sudo apt-get install python-testresources
sudo pip install pyulog
```

• Install pandas:

```
sudo apt-get install python-pandas
```

Recording a flight log

A new flight log is recorded every time the flight controller is powered on (and are stored when it powered off). To record a new flight log:

- In QGroundControl, click on the "page and magnifying glass" symbol in the top left corner. Select **Mavlink Console**.
- To start recording a new flight log, enter reboot into the command terminal.
- To stop recording, enter reboot into the command terminal again.
- Flight data is logged using the .ulog file format.

```
**Note:** Optical flow must be started *after* the first reboot
```

Accessing a flight log

You can access your flight logs (stored as .ulg files) in /var/lib/mavlink-router/


Converting .ulg file to .csv file

In this nootbook we will work with a pandas dataframe. In order to create a pandas dataframe of flight log data, we must first convert the .ulg file to .csv files (one .ulg file will be split into multiple .csv files, each containing specific flight infomation). This can be done with the following command:

```
ulog2csv <your-ulg-file>.ulg
```

- The unfiltered accelorometer data is stored in the 'sensor_combined' .csv file
- The filtered accelorometer date is stored in the 'estimator_status'.csv file

Relationship between acceleration, velocity and position




Let's see how integration works in python using constant acceleration.

Idealized Acceleration

```
In [5]:
        import pandas as pd
         import numpy as np
         import scipy.integrate
         import matplotlib.pyplot as plt
In [6]: # Example acceleration data representing constant acceleration over a per
        ##Just run this code
         data = [(0, 1), (1, 1), (2, 1), (3, 1), (4, 1), (5, 1), (6, 1), (7, 1), (
        times = []
         accel = []
         for point in data:
             times.append(point[0])
             accel.append(point[1])
         # Plot acceration vs. time
         fig,ax = plt.subplots()
         ax.plot([time for time in times], accel)
         ax.set ylabel('acceleration (m/s^2)')
         ax.set xlabel('time (sec)')
         fig.set size inches(10,4)
         1.04
       acceleration (m/s^2)
         1.02
         1.00
         0.98
         0.96
                                                                                  10
```

time (sec)

```
ax.plot([time for time in times], vel)
         ax.set ylabel('velocity (m/s)')
         ax.set_xlabel('time (sec)')
         fig.set size inches(10,4)
        AttributeError
                                                    Traceback (most recent call las
        t)
        Cell In[9], line 3
              1 # Integrate acceration to get the drone's velocity at each time
              2 ##Run this code and see how integration works in python
        ----> 3 vel = scipy.integrate.cumtrapz(accel, x = times, initial = 0)
              5 # Plot velocity vs. time
              6 fig,ax = plt.subplots()
        AttributeError: module 'scipy.integrate' has no attribute 'cumtrapz'
In [10]: vel = scipy.integrate.cumulative trapezoid(accel, x = times, initial = 0)
         # Plot velocity vs. time
         fig,ax = plt.subplots()
         ax.plot([time for time in times], vel)
         ax.set ylabel('velocity (m/s)')
         ax.set xlabel('time (sec)')
         fig.set size inches(10,4)
         fig.set size inches(10,4)
          10
           8
        velocity (m/s)
           6
           4
           2
           0
                                                       6
                                                                                 10
                                             time (sec)
In [11]: # Integrate velocity to get the drone's position at each time
         # YOUR CODE HERE
         pos = scipy.integrate.cumulative trapezoid(vel, x = times, initial = 0)
         # Plot position vs. time
         fig,ax = plt.subplots()
         ax.plot([time for time in times], pos)
         ax.set ylabel('position (m)')
         ax.set xlabel('time (sec)')
         fig.set size inches(10,4)
```



State estimation in UAV

You just saw how it works in python. Then, let's see how it works in measured data of the drone. We will fly the drone and give you flight log data(ulg) file. Your mission is analyzing the data, estimate and plot the position in x direction, then compare it to the kalman filter data.

For visual reference, here is a video of the flight from which the flight log was generated:

https://drive.google.com/file/d/1tmNqJppgiuaaBKqzV_VnTG3gkm_FK_E-/view?usp=sharing

Load log data

The first data frame we will create contains the accelerations measured by the drone's accelerometer. The columns accelerometer_m_s2[0], accelerometer_m_s2[1], and accelerometer_m_s2[2] contain the accelerations measured in the XYZ body frame (in m/s/s).

accelerometer_t	gyro_integral_dt	gyro_rad[2]	gyro_rad[1]	gyro_rad[0]	timestamp		Out[13]:
	4000	0.000636	0.005919	-0.000370	711784461	0	
	3999	-0.000449	0.002845	-0.001241	711788460	1	
	4000	0.001223	-0.000254	-0.001636	711792460	2	
	4005	0.000949	-0.004840	-0.000897	711796465	3	
	3995	0.001539	0.004207	0.001670	711800460	4	

The second data frame we will create contains state estimation data that has been filtered by an algorithm called the Extended Kalman Filter (EKF). The EKF processes sensor measurements from multiple sources (IMU, magnitometer, range finder, optical flow, etc.) and blends them together to get a much more accurate estimation of the drone's state. The columns states[4], states[5], and states[6] contain the velocities in the NED frame (in m/s).

```
In [15]: # Load EKF data as a pandas data frame
    ekf_data = pd.read_csv('accelerometer_filtering_test_flight_estimator_sta
    ekf_data.head()

Out[15]: timestamp states[0] states[1] states[2] states[3] states[4] states[5] states[4]

O 711776971 0.995747 0.014194 -0.003589 -0.090957 0.003736 -0.004825 -0.00061

1 711976949 0.995746 0.014237 -0.003573 -0.090966 0.001190 -0.002321 -0.00080

2 712180946 0.995746 0.014342 -0.003493 -0.090950 -0.004227 0.003577 -0.00180

3 712385617 0.995748 0.014296 -0.003567 -0.090937 -0.002695 0.001662 -0.00157


4 712589645 0.995749 0.014289 -0.003642 -0.090921 0.001124 0.000372 -0.00111
```

5 rows × 72 columns


Filter the accelerometer data

```
In [18]: # Acceleration data in the XYZ body frame (m/s/s)
         accel x = sensor data['accelerometer m s2[0]'].tolist()
         accel y = sensor data['accelerometer m s2[1]'].tolist()
         accel z = sensor data['accelerometer m s2[2]'].tolist()
         def get times(timestamps):
             Given a list of timestamps (in microseconds), returns a list of times
                 Args:
                      - timestamps = list of timestamps (microseconds)
                 Returns: list of times (seconds)
             start = timestamps[0]
             k = 1.0/1000000
             times = []
             for timestamp in timestamps:
                 time = k * (timestamp - start)
                 times.append(time)
             return times
         # Convert timestamps into a list of times (in sec) starting at t = 	heta.
         sensor times = get times(sensor data.index.tolist())
         # Plot acceleration vs. sensor time (we will only plot acceleration in th
         fig,ax = plt.subplots()
         # YOUR CODE HERE
         ax.plot(sensor times, accel x)
```

```
ax.set_ylabel('accel_x (m/s^2)')
ax.set_xlabel('time (sec)')
fig.set_size_inches(10,4)
```



```
In [19]: # Low pass filter example (not used)
         def low pass filter(sequence, windowsize):
             positions = len(sequence) - windowsize + 1
             windows = []
             for i in range(positions):
                 window = np.array(sequence[i:i+windowsize])
                 mean = window.mean()
                 windows.append(mean)
             return np.array(windows)
         # Apply a low pass filter to the accelerometer data
         windowsize = 200
         lp accel x = np.convolve(accel x, np.ones((windowsize,))/windowsize, mode
         lp_accel_y = np.convolve(accel_y, np.ones((windowsize,))/windowsize, mode
         lp accel z = np.convolve(accel z, np.ones((windowsize,))/windowsize, mode
         # Plot lpf acceleration vs. time (we will only plot acceleration in the 	imes
         fig,ax = plt.subplots()
         ax.plot([time for time in sensor times], lp accel x)
         ax.set ylabel('lp accel x (m/s^2)')
         ax.set xlabel('time (sec)')
         fig.set_size_inches(10,4)
```




Calculate change in position

With flight logs, you can estimate position by integrating acceleration. See how it looks

```
In [24]: # Integrate acceration to get the drone's velocity at each time
    # YOUR CODE HERE
    vel_x = scipy.integrate.cumulative_trapezoid(accel_x, x =sensor_times, in

# Integrate velocity to get the drone's position at each time
    lp_pos_x = scipy.integrate.cumulative_trapezoid(vel_x, x = sensor_times,

# Plot position vs. time (we will only plot acceleration in the x directifig,ax = plt.subplots()
    ax.plot([time for time in sensor_times], lp_pos_x)
    ax.set_ylabel('lp_pose_x (meters)')
    ax.set_xlabel('time (sec)')
    fig.set_size_inches(10,4)
```



Kalman filter

As you can see from the above result, it is quite different from what you expected. The estimated position came out to near 20 meters! To solve the problem, one answer is using Kalman filters. You can estimate your states more accurately with it. Below is some code to extract Kalman filter information that is stored during the test flight. Using this data, calculate the position again and compare with the above sensor data.


```
In [29]: # EKF velocity data in the NED frame (m/s)
    ekf_vel_x = ekf_data['states[4]'].tolist()
    ekf_vel_y = ekf_data['states[5]'].tolist()
    ekf_vel_z = ekf_data['states[6]'].tolist()

# Convert timestamps into a list of times (in sec) starting at t = 0.
    ekf_times = get_times(ekf_data.index.tolist())

# Integrate EKF velocity to get the drone's position at each time
    ekf_pos_est_x = scipy.integrate.cumulative_trapezoid(ekf_data['states[4]'

# Plot position vs. time (we will only plot acceleration in the x directifig,ax = plt.subplots()
    ax.plot([time for time in ekf_times], ekf_pos_est_x)
    ax.set_ylabel('ekf_pose_x (meters)')
    ax.set_xlabel('time (sec)')
```

In []:



Compare gained position with estimated position in karman

Actually, kalman filter data has its estimated possition. Compare the above data you got from integrating acceleration with the data in kalman filter. (state[7] indicates the position estimation from the kalman filter)

```
In [30]:
         # EKF position data in the NED frame (m/s)
          ekf_pos_x = ekf_data['states[7]'].tolist()
          ekf_pos_y = ekf_data['states[8]'].tolist()
          ekf pos z = ekf data['states[9]'].tolist()
          # Plot position vs. time (we will only plot acceleration in the x directi
          fig,ax = plt.subplots()
          ax.plot([time for time in ekf_times], ekf_pos_est_x, [time for time in ek
          ax.set_ylabel('ekf_pose_x (meters)')
          ax.set xlabel('time (sec)')
          ax.legend(['pos integrated from ekf vel', 'pos direct from ekf'])
          fig.set size inches(10,4)
            1.75
                     pos integrated from ekf vel
            1.50
                     pos direct from ekf
            1.25
        ekf_pose_x (meters)
            1.00
            0.75
            0.50
            0.25
            0.00
           -0.25
                0.000000
                           0.000025
                                      0.000050
                                                0.000075
                                                           0.000100
                                                                      0.000125
                                                                                0.000150
                                                   time (sec)
```